



2/15



3/15






FIG. 5

DEVICE ID	DEVICE TYPE		
IP CONFIG (S	IP CONFIG (STATIC/DHCP)		
TELCO	TELCO LOGINS		
TUNN	TUNNEL ID		
	•		
WEB SERV	WEB SERVER PAGES		
GUI INFO			
DNS INFO			
DHCP INFO			
PPP INFO			




FIG. 7

LOG IN

USER ID: PASSWORD: LOG IN
LOG IN

FIG. 12

STATUS {SYSTEM MESSAGE} AS OF {PC TIME}	
{ERROR MESSAGE}	DISCONNECT
	VIEW SYSLOG
	CLOSE
AT&T WORLDNET @HOME UUU ••• UU VVV ••• VV WWW ••• WW XXX ••• XX YYY ••• YY ZZZ ••• ZZ	
CONNECT EDIT COPY D	ELETE

FIG. 8

{SYSTEM MESSAGE} AS OF {PC TIME} {ERROR MESSAGE}	STATUS DISCONNECT VIEW SYSLOG CLOSE
SELECT A CONNECTION FROM THE LIST OR CREATE A AT&T WORLDNET HOME UUU ••• UU VVV ••• VV WWW ••• WW XXX ••• XX YYY ••• YY ZZZ ••• ZZ CONNECT CONNECT	NEW CONNECTION. FIELDS; SEE FOLLOWING))) DELETE

FIG. 9

{SYSTEM MESSAGE} AS OF {PC TIME} {ERROR MESSAGE}	STATUS DISCONNECT VIEW SYSLOG CLOSE
SELECT A CONNECTION FROM THE LIST OR CREATE A NEW CONNECTION. AT&T WORLDNET HOHOME UUU ••• UU VVV ••• VV WWW ••• WW XXX ••• XX YYY ••• YY ZZZ ••• ZZ DIAL—UP CONNECTION — {NAME OF CONNECTION} USER ID: {USER ID} PASSWORD: ************************************	

FIG. 10

{SYSTEM {ERROR N	MESSAGE} AS OF {PC TIME} MESSAGE}	STATUS DISCONNECT VIEW SYSLOG CLOSE
SELECT A CON AT&T WORLDNET @HOME UUU • • • UU VVV • • • VV WWW • • • WW XXX • • • XX YYY • • • YY ZZZ • • • ZZ	DIAL-UP CONNECTION - USER ID: {USER ID} PAS CUSTOMIZED MODEM DIAL ATDT*70, 18005551234	{NAME OF CONNECTION} SSWORD: ********* L STRING:

FIG. 11

(CVCTEN 1/20010E) 10 05 (D0 TH/E)	STATUS
{SYSTEM MESSAGE} AS OF {PC TIME} {ERROR MESSAGE}	VIEW SYSLOG
	CLOSE
SELECT A CONNECTION FROM THE LIST OR CREATE	E A NEW CONNECTION.
AT&T WORLDNET @HOME UUU ••• UU VVV ••• VV WWW ••• WW XXX ••• XX YYY ••• YY ZZZ ••• ZZ CONNECT EDIT NETWORK CONNECTI MASK: SOME STATEMAY: STATEMA	IP_ADDRESS} {MASK_ADDRESS}

FIG. 13

CONNECTING •••

CONNEC	T TO {NAME} • • •	STATUS DISCONNECT VIEW SYSLOG
VCS OFFICE(SM) VCS AGENT(SM) PAT	SERVICE NAME} LOGIN SERVICE URL: http://aaaa.resec SUBSCRIBER ID: 123.45.67.89 PASSWORD: 255.0255.0 SAVE PASSWORD LOGIN TRY AGAIN MAIN ME]

FIG. 14

NEW CONNECTION

Step 1: Name			
WHAT IS THE NAME OF THIS CONNECTION?			
Step 2: Connection Type			
O DIAL-UP CONNECTION A DIAL-UP CONNECTION USES A MODEM AND OBTAINS CONNECTION BY DIALING INTO A NUMBER.	NETWORK CONNECTION A NETWORK CONNECTION USUALLY CONNECTS THROUGH LOCAL AREA NETWORK (LAN), CABLE MODEM, OR DSL.		
Step 3: Specific Information			
FOR DIAL UP CONNECTION • • •	FOR NETWORK CONNECTION • • •		
USER ID: PASSWORD: USE STANDARD DIAL-UP CONFIGURATION PHONE NUMBER TO DIAL: - OPTION: DIAL TO ACCESS ON OUTSIDE LINE. - OPTION: DIAL TO DISABLE CALL WAITING. - OR - USE CUSTOMIZED MODEM DIALING STRING	O USE DHCP HOST: - OR - USE FIXED IP ADDRESS IP ADDRESS: MASK: GATEWAY:		
SAVE START	OVER CANCEL		

FIG. 15

EDIT CONNECTION

NAME: {NAME}	DIAL-UP CONNECTION
USER ID:	
⊙ USE STANDARD DIAL-UP COM	VFIGURATION
PHONE NUMBER TO DIAL - OPTION: DIAL - OPTION: DIAL - OR - OUSE CUSTOMIZED DIALING ST	9 TO ACCESS AN OUTSIDE LINE. *70 TO DISABLE CALL WAITING.
SAVE SAVE AS	START OVER CANCEL

FIG. 16

EDIT CONNECTION

NAME: {NAME}	NETWORK CONNECTION
⊙ USE DHCP CLIENT:	
- OR - OUSE CUSTOMIZED DIALING STRING IP ADDRESS:	23.45.678.90
MASK: Z	255.254.253.252 123.4.56.789
SAVE STAI	RT OVER CANCEL